

Economy Reboundable Lane Delineator Installation

Tools Required:

- ¼" x 2+" Masonry Drill Bit
- Cordless drill or Hammer Drill
- Small Sledgehammer
- Leaf blower or broom

Installation Instructions:

- 1) Position the Reboundable Lane Delineator where you would like it installed.
- 2) Using the drill bit and drill, mark the surface where the four (4) holes in the Reboundable Lane Delineator meet the surface.
- 3) Move the Reboundable Lane Delineator.
- 4) Mark drill bit with tape or drill stop so that it drills a hole 1 ½" deep.
- 5) Drill four (4) holes in the pavement when you marked the holes.
- 6) Using the leaf blower or broom, clear the debris from the holes.
- 7) Put a nut on the top of each expansion bolt.
- 8) Put the Reboundable Lane Delineator down over the four (4) holes you drilled.
- 9) With the nut at the top of the threaded portion of the expansion bolts facing up, use the small sledgehammer to drive the four (4) expansion bolts thru the four (4) holes molded into the pop-up delineator and into the holes you drilled in the pavement surface, so that the nut is flush with the top of the Reboundable Lane Delineator.
- 10) Insert the four (4) 'Nail Like' expanders into the centers of the expansion bolts.
- 11) Drive Expanders flush with small sledge.
- 12) Check Reboundable Lane Delineator for security.